

Cabin Air Filter Installation Guide

- Acura (2002 - 04)
- Civic (01 – 05)
- Civic Hybrid (03 - 05)
- CRV (02 - 05)
- Element (03 – 05)

FILTER PLACEMENT: **In Glove Box**
QTY : **2**

Installation: (5 ~ 10 min.)



Easy




Moderate



Difficult



Professional



CAUTION

Ensure ignition switch is OFF before attempting to change the Cabin Air Filter!

INSTRUCTIONS:*

1. Open Glove Box.
2. Pull sides of glove box compartment to release the box and pull it forward away from dash.
3. You are now able to see the cabin air filter access panel.
4. Remove the cabin air filter access panel.
5. Replace the used cabin air filter with a new Pentius Cabin Air Filter, ensuring that the filter is placed with air flow markings in the correct direction (pleats upward).
6. Replace all components in the reverse order of removal.

* Note that Cabin Air filter replacement instructions may be representative for certain vehicles.