

Cabin Air Filter Installation Guide

- Acura TL, TLX (2004 - 2007)
RDX (2007)
- Honda Accord (2003 – 2007)
Civic (2006 – 2007)

FILTER PLACEMENT: **In Glove Box**
QTY: **1**

Installation: (5 ~ 10 min.)



Easy




Moderate



Difficult



Professional



CAUTION

Ensure ignition switch is OFF before attempting to change the Cabin Air Filter!

INSTRUCTIONS:*

1. Open Glove Compartment.
2. Disconnect the right side of glove box by unhooking stop.
3. Push in on top of glove box side of door from both right and left sides.
4. Remove the cabin air filter housing by pulling both tabs located at each side of housing.
4. Remove and replace the used cabin air filters with new Pentius Cabin Air Filters.
5. Verify that the air flow arrows are in the correct direction if noted on filter.
6. Replace all components in the reverse order of removal.

* Note that Cabin Air filter replacement instructions may be representative for certain vehicles.