



Cabin Air Filter Installation Guide

- Hyundai Accent 1.6L (2003 – 2006)

FILTER PLACEMENT: **Behind Glove Box**
QTY: **2**

Installation: (15 ~ 20 min.)



CAUTION

Ensure ignition switch is OFF before attempting to change the Cabin Air Filter!

INSTRUCTIONS:*

1. Open Glove Box
2. Remove the glove box stopper in order to lower the glove box completely.
3. You are now able to see the cabin air filter access panel.
4. Remove one end of the vent cable to gain access to the panel.
5. Remove the cabin air filter access panel by pressing the release.
6. Remove and replace the used cabin air filter with a new Pentius Cabin Air Filter ensuring that the filter is placed with air flow markings in the correct direction (if applicable).
7. Replace all components in the reverse order of removal.

* Note that Cabin Air filter replacement instructions may be representative for certain vehicles.